825

Non-return valve with dual-plate 05 System

Technical Data Sheet







Description

The 825 non-return valve's tightness is ensured by the spring force distribution on the plates guaranteeing a good press on the seat's seal.

• Operating position : horizontal and vertical

Compact

Very low head loss

• Sealing : metal on elastomere seat

• FKM seal



825

Non-return valve with dual-plate - 05 System

DN		PN	PFA	PS in bar				Cat.	Ref.	Weight
"	mm		in bar	L1	L2	G1	G2	Out.	11011	Kg
2	50	25	25	25	25	20	25	I	149B3170	2,5
2 1/2	65	25	25	25	25	15	25	1	149B3171	3,2
3	80	25	25	25	25	12	25	1	149B3172	3,4
4	100	25	25	20	25	10	25	I	149B3173	5,6
5	125	25	25	16	25	0,5	25	I	149B3174	8,1
6	150	25	25	13	25	0,5	23	I	149B3175	10,4
8	200	25	25	10	25	0,5	17	1	149B3176	18,5
10	250	25	25	10	25	0,5	14	I	149F020384	29,5
12	300	25	25	10	25	0,5	11	I	149F020386	44,1
14	350	25	25	10	25	Х	10	I	149B2669	78


Important notice:

The indicated pressure for the different categories of fluids (L1/L2/G1/G2) is under no condition a guarantee of use. Therefore, it is essential to validate the use of products under given operating conditions. The operating instructions are available on our website www.socla.com or by requesting from our sales department.

Technical features				
Operating temperature	-10 °C at 130 °C			
Permissible operating pressure (PFA) in water	See table above			
Maximum permissible pressure (PS) other mediums	See table above			
Connection	Mounting between flanges, PN see table			
Mediums	Clear liquids, gas, hydrocarbons			

Nomenclature and materials

N°	Description		Materials	EURO	ANSI
1	Body		Stainless steel	X5CrNiMo17-12-2	AISI 316
2	Plates		Stainless steel	X5CrNiMo17-12-2	AISI 316
3	Seal		FKM		
4	Spring		Stainless steel	X5CrNiMo17-12-2	AISI 316
5	Stem		Stainless steel	X5CrNiMo17-12-2	AISI 316
6	Bearings		PTFE		
7	Eye bolt	DN > 150	Steel XC15		
8	Plug		Stainless steel	X5CrNiMo17-12-2	AISI 316





Approvals



International construction Standards:

CE conformity directive 2014/68/UE Flange driling according tot EN 1092-2 Overall dimensions according to EN558-1 series 50

Application

Pumping, supply, general industry.

Use of these valves on circuits equipped with piston pump or piston compressor is not recommended.

Installation

Installation:

Before putting valve into operation, check that:

- the working conditions are compatible with the details given on the identification plate, the instruction notice and the manufacturer's detail.
- the valve works effectively when tried (carry out a few opening and closing operations of the closing system),
- the valve is free-pollution inside.

On a new installation or after maintenance, the circuit must be rinsed with the valve completely open in order to remove solid matter which may damage the internal parts of the valve.

Commissioning:

The installation should be put under pressure progressively to avoid damage which might occur to internal components.

Make sure that when flow stops the valve maintains pressure well and that there is no water-hammer which might damage the valve or installation.

If there is water-hammer, an anti-water hammer system must be added to the installation.

During a prolonged stoppage, a change in the state of the fluid may result in damage when the installation is brought back into service (solidification...).

Establish an adequate procedure program for cleaning the system.

Maintenance

• Removing:

- 1. Unscrew the 4 plugs (N° 5) and remove the 4 seals (N° 4). Tip over the body (N° 1) if necessary
- 2. Remove the upper stem (N° 3)
- 3. Use this to remove the lower stem (N° 3)

WARNING: Keep the springs (N° 8 and 8*) in compression during this operation.

Remove the 2 plates (N° 9) and the bearings (N° 6 and 6*)


• Reassembly :


Before reassembling the valve, check the condition of the seal. If necessary, clean and grease it by using appropriate grease.

- 1. Put in place 2 seals (N° 5) on the same side of the body (N° 1)
- Thread 2 plugs (N° 5) on the same side with a stop on the body (N° 1)
- 3. Place the 2 wings flat (N° 9) on the body (N° 1)
- 4. Engage the lower stem (N° 3) by sliding it into the body (N° 1), while positioning in the following order:
 - The first bearing (N° 6)
 - The first ear of the plate (N $^{\circ}$ 9)
 - The second bearing (N° 6)
 - The first ear of the second plate (N° 9)
 - The spring (N° 7)
 - The bearing (N° 6*)
 - The spring (N° 8*)
 - The second ear of the plate (N° 9)
 - The third bearing (N° 6)
 - The second ear of second plate (N° 9)
 - The fourth bearing (N° 6)
- 5. Push the stem against the seal (N° 4) by using the second stem to complete the operation
- 6. Put in place the upper stem (N° 3)
- 7. Place the 2 last seals (N° 4)
- 8. Screwed the 2 last plugs (N° 5)
- 9. Tighten then at Nm torques

Once the reassembly completed, test the device to verify its tightness.










Operation

Direction for use:


- Solid line: Valve completely open
- Dotted line: opening stage of valve



825 - Headloss chart

Sizing

-	A	В	С	D
"	mm	mm	mm	mm
2	50	54	60	109
2 1/2	65	54	73	129
3	80	57	89	144
4	100	64	114	170
5	125	70	141	194
6	150	76	168	220
8	200	95	219	286
10	250	108	273	340
12	300	143	324	403
14	350	184	356	460



The descriptions and photographs contained in this product specification sheet are supplied by way of information only and are not binding.

Socia reserves the right to carry out any technical and design improvements to its products without prior notice. Warranty: All sales and contracts for sale are expressly conditioned on the buyer's assent to Socia terms and conditions found on its website at www.socia.com. Socia hereby objects to any term, different from or additional to Socia terms, contained in any buyer communication in any form, unless agreed to in a writing signed by an officer of Socia.



A WATTS Brand

Socla sas

K۷

 m^3/H

35,7

69

116

212

458

685

1447

2271

3709

4293

ζ

7,81

5,90

4,80

3,60

1,90

1,70

1,20

1,20

0,94

1,30

365 rue du Lieutenant Putier • 71530 Virey-Le-Grand • France
Tel. +33 03 85 97 42 00 • Fax +33 03 85 97 42 42
contact@wattswater.com • www.socla.com
ISO 9001 version 2015 / ISO 18001